

---

# IGNITION

IGNITION SYSTEM .....	IG-1
DISTRIBUTOR .....	IG-7

# IGNITION SYSTEM ON-VEHICLE INSPECTION

ISSUE-01


## Spark Test






### CHECK THAT SPARK OCCURS

- Disconnect the high-tension cord (from the ignition coil) from the distributor cap.
- Hold the end approx. 12.5 mm (0.50 in.) from the body ground.
- See if spark occurs while engine is being cranked.

**NOTICE:** To prevent gasoline from being injected from injectors during this test, crank the engine for no more than 5 - 10 seconds at time.

If the spark does not occur, perform the test as follows:





**High-Tension Cords**

**1. DISCONNECT HIGH-TENSION CORDS FROM SPARK PLUGS**

- (a) Remove the 6 screws and No.2 cylinder head cover.
- (b) Disconnect the high-tension cords at the rubber boot. Do not pull on the high-tension cords.

**NOTICE:** Pulling on or bending the cords may damage the conductor inside.

**2. DISCONNECT HIGH-TENSION CORD FROM IGNITION COIL**

**3. DISCONNECT HIGH-TENSION CORDS FROM DISTRIBUTOR CAP**

- (a) Using a screwdriver, lift up the lock claw and disconnect the holder from the distributor cap.
- (b) Disconnect the high-tension cord at the grommet. DO NOT pull on the cords.

**NOTICE:** Pulling on or bending the cords may damage the conductor inside.

**4. INSPECT HIGH-TENSION CORD RESISTANCE**

Using an ohmmeter, measure the resistance.

**Maximum resistance:**


25 kΩ per cord

If the resistance is greater than maximum, check the terminals. If necessary, replace the high-tension cord.


**5. RECONNECT HIGH-TENSION CORDS TO DISTRIBUTOR CAP**

- (a) Connect the holder and grommet portion to the distributor cap as shown in the illustration.

**NOTICE:** Check that the holder is correctly installed to the grommet and distributor cap as shown in the illustration.



- (b) Check that the lock claw of the holder is engaged by lightly pulling the holder.




## 6. RECONNECT HIGH-TENSION CORDS TO SPARK PLUGS

- (a) Secure the high-tension cords with the clamps as shown in the illustration.
- (b) Reinstall the No.2 cylinder head cover with 6 screws.

## Spark Plugs

### NOTICE:

- Never use a wire brush for cleaning.
- Never attempt to adjust the electrode gap on a used spark plug.
- Spark plugs should be replaced every 100,000 km (60,000 miles).



## 1. INSPECT ELECTRODE

Using a megger (insulation resistance meter), measure the insulation resistance.

**Standard correct insulation resistance:**

**10 MΩ or more**

If the resistance is less than specified, proceed to step 4.


**HINT:** If a megger is not available, the following simple method of inspection provides fairly accurate results.

### Simple Method:

- (a) Quickly race the engine to 4,000 rpm 5 times.
- (b) Remove the spark plug. (See step 2)
- (c) Visually check the spark plug.  
If the electrode is dry ... OK  
If the electrode is wet ... Proceed to step 3
- (d) Reinstall the spark plug. (See step 6)

## 2. REMOVE SPARK PLUGS

Using a spark plug wrench, remove the 4 spark plugs.



### 3. VISUALLY INSPECT SPARK PLUGS


Check the spark plug for thread damage and insulator damage.

If abnormal, replace the spark plug.

Recommended spark plug:

DENSO: PK20R11

NGK: BKR6EP-11



### 4. INSPECT ELECTRODE GAP

Maximum electrode gap for used spark plug:

1.3 mm (0.051 in.)

If the gap is greater than maximum, replace the spark plug.

Correct electrode gap for new spark plug:

1.1 mm (0.043 in.)

**NOTICE:** If adjusting the gap of a new spark plug, be only the base of the ground electrode. Do not touch the tip. Never attempt to adjust the gap on the used plug.

### 5. CLEAN SPARK PLUGS

If the electrode has traces of wet carbon, allow it to dry and then clean with a spark plug cleaner.


Air pressure:

Below 588 kPa (6 kgf/cm<sup>2</sup>, 85 psi)

Duration:

20 seconds or less

**HINT:** If there are traces of oil, remove it with gasoline before using the spark plug cleaner.



### 6. REINSTALL SPARK PLUGS

Using a spark plug wrench, install the 4 spark plugs.


Torque: 18 N·m (180 kgf·cm, 13 ft·lbf)

### 7. RECONNECT HIGH-TENSION CORDS TO SPARK PLUGS

#### Ignition Coil

**NOTICE:** "Cold" and "Hot" in the following sentences press the temperature of the coils themselves. "Cold" is from -10°C (14°F) to 50°C (122°F) and "Hot" is from 50°C (122°F) to 100°C (212°F).

1. DISCONNECT IGNITION COIL CONNECTOR
2. DISCONNECT HIGH-TENSION CORD FROM IGNITION COIL



**3. INSPECT PRIMARY COIL RESISTANCE**


Using an ohmmeter, measure the resistance between the positive (+) and negative (-) terminals.

Primary coil resistance:

Cold: 0.36 - 0.55  $\Omega$

Hot: 0.45 - 0.65  $\Omega$

If the resistance is not as specified, replace the ignition coil.



**4. INSPECT SECONDARY COIL RESISTANCE**

Using an ohmmeter, measure the resistance between the positive (+) and high-tension terminals.

Secondary coil resistance:


Cold: 9.0 - 15.4 k $\Omega$

Hot: 11.4 - 18.1 k $\Omega$

If the resistance is not as specified, replace the ignition coil.

**5. RECONNECT HIGH-TENSION CORD TO IGNITION COIL**

**6. RECONNECT IGNITION COIL CONNECTOR**




**Distributor**

**NOTICE:** "Cold" and "Hot" in the following sentences express the temperature of the coils themselves. "Cold" is from -10°C (14°F) to 50°C (122°F) and "Hot" is from 50°C (122°F) to 100°C (212°F).

**1. REMOVE DISTRIBUTOR CAP**

Remove the 2 bolts, and disconnect the distributor cap from the distributor housing.



**2. REMOVE ROTOR**

**3. INSPECT AIR GAP**


Using SST, measure the air gap between the signal rotor and pickup coil projection.

SST 09240-00020

Air gap:

0.2 - 0.5 mm (0.008 - 0.020 in.)

If the air gap is not as specified, replace the distributor housing assembly.



**4. DISCONNECT DISTRIBUTOR CONNECTOR**

**5. INSPECT SIGNAL GENERATOR (PICKUP COIL) RESISTANCE**

Using an ohmmeter, measure the resistance between terminals.

Terminal	Cold	Hot
G1 and G $\ominus$	125 - 200 $\Omega$	160 - 235 $\Omega$
G2 and G $\ominus$	125 - 200 $\Omega$	160 - 235 $\Omega$
NE and G $\ominus$	155 - 250 $\Omega$	190 - 290 $\Omega$

If the resistance is not as specified, replace the distributor housing assembly.

6. **RECONNECT DISTRIBUTOR CONNECTOR**
7. **REINSTALL ROTOR**
8. **REINSTALL DISTRIBUTOR CAP**


Install a new packing and distributor cap with the 2 bolts

**Igniter**

**(See spark test)**


# DISTRIBUTOR COMPONENTS

30574-02



Non-reusable part

T 30656



Y 308520




## REMOVAL

1. **DISCONNECT DISTRIBUTOR CONNECTOR**
2. **DISCONNECT HIGH-TENSION CORD FROM DISTRIBUTOR CAP**
3. **REMOVE DISTRIBUTOR**
  - (a) Remove the hold-down bolt, and pull out the distributor.
  - (b) Remove the O-ring from the distributor housing.

## DISASSEMBLY


1. **REMOVE DISTRIBUTOR CAP**  
Remove the 3 bolts, distributor cap and packing.
2. **REMOVE ROTOR**  
Remove the 2 screws and rotor.



## INSPECTION


### INSPECT SHAFT

Turn the shaft and check that it is not rough or worn. If it feels rough or worn, replace the distributor housing assembly.



## REASSEMBLY


1. **INSTALL ROTOR**
  - (a) Align the hollow of the signal rotor with the profile of the rotor.
  - (b) Install the rotor with the 2 screws.
2. **INSTALL DISTRIBUTOR CAP**
  - (a) Install a new packing to the distributor housing.
  - (b) Install the distributor cap with the 3 bolts.



100L-04

**INSTALLATION****1. SET NO. 1 CYLINDER TO TDC/COMPRESSION**

Turn the crankshaft clockwise, and position the slit of the intake camshaft as shown in the illustration.

**2. INSTALL DISTRIBUTOR**

- (a) Install a new O-ring to the housing.
- (b) Apply a light coat of engine oil on the O-ring.
- (c) Align the cutout of the coupling with the line of the housing.
- (d) Insert the distributor, aligning the center of the flange with that of bolt hole on the cylinder head.
- (e) Tighten the hold-down bolt.

Torque: 23 N·m (230 kgf·cm, 17 ft·lbf)

**3. CONNECT HIGH-TENSION CORDS TO SPARK PLUGS**

Firing order:

1-3-4-2

**4. CONNECT HIGH-TENSION CORD TO IGNITION COIL****5. CONNECT DISTRIBUTOR CONNECTOR**